



Manual

Inclinometer IN88

SAE J1939

Table of Contents

1 Document	4
2 General Information	5
2.1 Target Group.....	5
2.2 Symbols used / Classification of the Warnings and Safety instructions.....	5
3 Product Description	7
3.1 Technical Data	7
3.2 Interface Description SAE J1939	7
3.3 Supported Standards and Protocols	9
4 Installation	10
4.1 Electrical Installation	10
4.1.1 General Information for the Connection	10
4.1.2 Information for EMC-Compliant Installation	10
4.1.3 Connection Color Coding	12
4.1.4 Connection Legend.....	12
4.1.5 Terminal Assignment	12
4.1.6 Electrical Features	13
4.2 Mechanical Installation.....	13
4.2.1 General Information for the Mounting of Inclinometers.....	13
4.2.2 Axes Orientation.....	14
5 Commissioning and Operation	15
5.1 Function and Status LED	15
5.2 Quick Start Guide.....	15
5.2.1 Default Settings.....	15
5.2.2 Changing the Parameters	16
5.3 Protocol Features.....	17
5.3.1 Data Transmission	17
5.3.2 Layout of the Configuration Data PG	18
5.3.3 Layout of the Process Data PG	19
5.4 Configuration Parameters Description	20
5.4.1 Cycle Time - INCLIN_CFG_TxCycleTime.....	20
5.4.2 Bit Rate - INCLIN_CFG_BitRate	20
5.4.3 Node ID - INCLIN_CFG_NodeID	21
5.4.4 Termination - INCLIN_CFG_CAN_Termination.....	21
5.4.5 Resolution - INCLIN_CFG_Resolution	21
5.4.6 X Axis Scaling - INCLIN_CFG_LongOperatingPar	21
5.4.7 Preset Activation X Axis - INCLIN_SlopeLongPresetActivate	22
5.4.8 Preset Value X Axis - INCLIN_SlopeLongPresetValue	22
5.4.9 Y Axis Scaling - INCLIN_CFG_LatOperatingPar	23
5.4.10 Preset Activation Y Axis – INCLIN_SlopeLatPresetActivate.....	24
5.4.11 Preset Value Y Axis - INCLIN_SlopeLatPresetValue	24
5.4.12 Filter setting - INCLIN_CFG_FilterConfig.....	24

5.5	Process Data Description	25
5.5.1	Angle Longitudinal - IN88_Slope_Long	25
5.5.2	Angle Lateral - IN88_Slope_Lat.....	26
5.5.3	Temperature - IN88_Temperature	26
5.5.4	Overflow - IN88_Overflow	27
5.5.5	Position - IN88_BackFront	27
5.5.6	Orientation - IN88_Orientation	27
5.5.7	Error - IN88_Error	29
5.6	Examples	29
5.6.1	Example: Setting Configuration Data	29
5.6.2	Example: Resetting to Factory Settings	31
6	Contact	34
7	Annex	35
7.1	Angle calculation	35
7.1.1	1-axis inclinometer	35
7.1.2	2-axes inclinometer	35
7.2	Sensor filter	36
7.3	Decimal / Hexadecimal conversion table	38
	Glossary	40

1 Document

This is the English translation of the original manual in German language.

Publisher	Kübler Group, Fritz Kübler GmbH Schubertstraße 47 78054 Villingen-Schwenningen Germany www.kuebler.com
Issue date	02/2022
Copyright	© 2022, Kübler Group, Fritz Kübler GmbH

Text sources	Vector-Lösungen für Ihre SAE J1939-Vernetzung lxxat - SAE J1939 – eine kurze Einführung
Image sources	Vector-Lösungen für Ihre SAE J1939-Vernetzung lxxat - SAE J1939 – eine kurze Einführung

Legal Notices

All of the contents of this document are protected by the rights of use and copyrights . Any duplication, modification, further use and publications in other electronic or printed media, as well as their publication in the Internet, even partially, is subject to the previous written authorization by .

The brand names and product brands mentioned in this document are trademarks or registered trademarks of the respective titleholders.

Subject to errors and changes. The stated product features and technical data shall not constitute any guarantee declaration.

2 General Information






Please read this document carefully before working with the product, mounting it or starting it up.

2.1 Target Group

The device may only be planned, mounted, commissioned and serviced by persons having the following qualifications and fulfilling the following conditions:

- Technical training.
- Briefing in the relevant safety guidelines.
- Constant access to this documentation.
- In case of electrical equipment for potentially explosive atmospheres, the specialized personnel needs knowledge about the ignition protection category concept.
- For facilities in potentially explosive atmospheres, the authorized person must comply with the applicable country-specific regulations.

2.2 Symbols used / Classification of the Warnings and Safety instructions

 DANGER	<p>Classification:</p> <p>This symbol, together with the signal word DANGER, warns against immediately imminent threat to life and health of persons.</p> <p>The non-compliance with this safety instruction will lead to death or severe adverse health effects.</p>
 WARNING	<p>Classification:</p> <p>This symbol, together with the signal word WARNING, warns against a potential danger to life and health of persons.</p> <p>The non-compliance with this safety instruction may lead to death or severe adverse health effects.</p>
 CAUTION	<p>Classification:</p> <p>This symbol, together with the signal word CAUTION, warns against a potential danger for the health of persons.</p> <p>The non-compliance with this safety instruction may lead to slight or minor adverse health effects.</p>

ATTENTION	Classification: The non-compliance with the ATTENTION note may lead to material damage.
NOTICE	Classification: Additional information relating to the operation of the product, and hints and recommendations for efficient and trouble-free operation.

3 Product Description

3.1 Technical Data

Operating, storage and transport temperature range	-40 °C ... +85 °C
Supply Voltage and Current Consumption	10 ... 30 VDC 70 mA at 10 VDC 30 mA at 24 VDC 6 mA at 30 VDC
2-axes sensor Measuring range per axis	±85.00°
1-axes sensor: Measuring range	0 ... 359.99°
Internal process data cycle	20 ms
Function display	Triple LED (red/green/blue)
Bus connection	1 x M12 or 2 x M12
Sensor	MEMS system interface
Resolution	14 bits
Standard scale factor	Scaling off
Output	SAE J1939
Communication parameters	250 kbit/s (switchable to 500 kbit/s) 8 data bytes BAM CMDT
Interface	RS485 CAN High-Speed according to ISO 11898, CAN Specification 2.0 B


3.2 Interface Description SAE J1939

SAE J1939 is an open standard for networking and communication in the utility vehicles sector. Among possible applications, focus is set on the networking of the powertrain.

The use of the CAN technology for networking and communication and a manufacturer-independent interoperability are characteristic for J1939. The J1939 protocol comes from the international Society of Automotive Engineers (SAE) and operates on the physical layer with CAN Highspeed according to ISO 11898.


The SAE J1939 protocol uses CAN (Controller Area Network, ISO 11898-1 and ISO 11898-2) as the physical transmission layer. The CAN protocol plays a major role in the automotive networking and is a common method for the bit-serial communication between control units (Electronic Control Unit - ECU).

Typical control units are for example: the engine, transmission or brake control unit



IMG-ID: 118862859

Messages with a length exceeding 8 bytes are too large to suit in a single CAN data frame. So they must be divided in single packets by the transmitter to be then transmitted each in a CAN message. The receiver must reassemble the single fragments in the original order. A framework is provided in the J1939 standard for this purpose: a so-called transport protocol.




IMG-ID: 118864779

Before a CA uses an address, it must claim this address in the network. This procedure is called ADDRESS CLAIMING (ACL). The unique device name is used to solve conflicts during address allocation: the smaller the numerical value, the higher the priority.

When starting up, the CA transmits an ADDRESS CLAIM PGN (ACL, PGN 00EE00h) and waits a defined time for a response. If no other CA claims this address during this time, it can start with the normal communication.

Several documents apply for SAE J1939 according to the OSI layer model. The document number respectively refers to the assigned layer in the layer model. As practically all field bus protocols, layers 5 and 6 are not required by SAE J1939 and are therefore not specified. With J1939, the network management is organized decentrally, i. e. every control device must implement a minimum functionality. Since the network management can be considered as a separate unit, which accesses up to the hardware (layer 1), it is represented as an independent functional block on the right side of the picture..



IMG-ID: 118869643

3.3 Supported Standards and Protocols

SAE J1939 with two PGs:

- Configuration-receive PG (via CMTD transport protocol)
- Position and status transmit PG (without transport protocol)

The configuration PG allows performing node number allocation and CAN bit rate configuration directly via the CANbus. Alternatively, the node address can also be modified by means of the J1939 Commanded Address PG.

Moreover, scaling, preset values and some other additional parameters can be programmed via the CANbus. When transmitting the configuration-receive PG to the sensor, the configuration is immediately saved in the Flash memory of the microcontroller included in the sensor. The configuration remains preserved after switching off the operating voltage.

When switching on, all parameters are loaded from the Flash memory. The distribution of the data bytes among the transmit PG (the layout or mapping of the transmit PG) is defined in the device.

NOTICE	<p>PG Configuration</p> <p>The numbers of the J1939 PGs for sending the measured values and for configuration receipt are permanently stored in the device. On request, Kübler can also provide the devices with modified PG numbers.</p>
---------------	--

4 Installation

4.1 Electrical Installation

4.1.1 General Information for the Connection

ATTENTION	<p>Destruction of the device</p> <p>Before connecting or disconnecting the signal cable, always disconnect the power supply and secure it against switching on again.</p>
NOTICE	<p>General safety instructions</p> <p>Make sure that the whole plant remains switched off during the electrical installation.</p> <p>Make sure that the operating voltage is switched on or off simultaneously for the device and the downstream device.</p>
NOTICE	<p>Traction relief</p> <p>Always mount all cables with traction relief.</p>
NOTICE	<p>Interference susceptibility</p> <p>Proceed as follows:</p> <ul style="list-style-type: none"> • Connect the shield to the device housing. • Comply with the maximum cable length for stub lines and for the total length of the bus network. • Check the maximum supply voltage on the device.

4.1.2 Information for EMC-Compliant Installation

Requirements for cables

- Use exclusively shielded twisted-pair cables to connect the device.
- Comply with the maximum permissible connection cables length.

EMC acc. to EN 61326-1	Criterion A The device operates trouble-free, user data transmission proceeds without disturbance, internally stored data and configurations remain preserved	Criterion B During a failure, a disturbed transmission of the user data is allowed, internally stored data and configurations remain preserved
Interference immunity	Is achieved with a shielded line	Is not achieved with a shielded line
	Class A Industrial environment The device has a radiation according to Class A	Class B Living area The device has a radiation according to Class B
Radiation	Is not achieved with a shielded line	Is achieved with a shielded line

Shielding and equipotential bonding

- Apply the cable shield on a large contact area - ideally 360°. Use e. g. a shield terminal to this purpose.
- Pay attention to proper cable shield fastening.
- Preferably connect the shield on both sides with low impedance to the protective earth (PE), e.g. on the device and/or on the evaluation unit. In the event of potential differences, the shield must only be applied on one side.
- If shielding is not possible, appropriate filtering measures must be taken.
- If the protective earth should be connected to the shield on one side only, it must be made sure that no short-time overvoltages can appear on the signal and supply voltage lines.
- For the large-area connection of the cable shield, use the shield terminal for top hat rail mounting provided for this purpose.



IMG-ID: 9007199375147403

Order code	8.0000.4G06.0312
Material	Spring steel, galvanized
Shield diameter	3.0 ... 12.0 mm

Kübler offers a wide range of connection cables in various versions and lengths, see www.kuebler.com/connection-technology.

Kübler offers various solutions for EMC-compliant installation, e.g. shield terminals for the electrical cabinet, see www.kuebler.com/accessories.

4.1.3 Connection Color Coding

Part of the cables are identified by a color coding, part of them by a numerical coding. Abbreviation of the colors :

Abbreviation	Color	Abbreviation	Color
WH	White	BU	Blue
BN	Brown	RD	Red
GN	Green	BK	Black
YE	Yellow	VT	Violet
GY	Gray	GY-PK	Gray-Pink
PK	Pink	RD-BU	Red-Blue

ATTENTION



Destruction of the electronics

When confectioning the sensor cable, always take care to ensure sufficient ESD protection.

4.1.4 Connection Legend


+V: Supply voltage +V DC

0V: Ground GND (0V)

CAN_H: Positive CAN Signal (Dominant High)

CAN_L: Negated CAN-Signal (Dominant Low)

CAN_GND: CAN-Ground

PH : Connector housing (cable shield is applied on the connector housing), protective earth

4.1.5 Terminal Assignment

Isolate unused wires individually before commissioning.

Interface	Type of connection	1 x M12 connector, 5-pin						Pin arrangement
3	1	Bus IN						
		Signal	+V	0V	CAN_GND	CAN_H	CAN_L	
		Pin	2	3	1	4	5	

Interface	Type of connection	2 x M12 connector, 5-pin					Pin arrangement	
3	3	Bus OUT						
		Signal	+V	0V	CAN_GND	CAN_H		CAN_L
		Pin	2	3	1	4		5
3	3	Bus IN						
		Signal	+V	0V	CAN_GND	CAN_H		CAN_L
		Pin	2	3	1	4		5

NOTICE	<p>Connect the shield to the inclinometer housing</p> <ul style="list-style-type: none"> • If possible, mount all cables with traction relief. • Check the maximum supply voltage on the device.
---------------	---

4.1.6 Electrical Features


Display	LEDs
Interface	SAE J1939 (CAN)
Bus connection	1x M12 or 2x M12
Supply voltage	10 ... 30 VDC max. 20 mA

NOTICE	<p>Comply with the maximum cable length for stub lines and for the total length of the bus system.</p> <ul style="list-style-type: none"> • If possible, mount all cables with traction relief. • Check the maximum supply voltage on the device.
---------------	--

4.2 Mechanical Installation

4.2.1 General Information for the Mounting of Inclinometers

NOTICE	<p>Do not disassemble or open the inclinometer</p> <p>Inclinometer function may be lost partly or entirely.</p> <ul style="list-style-type: none"> • In no case disassemble the inclinometer entirely or partly. • Do not modify the inclinometer.
---------------	---



NOTICE

Do not expose the device to impact stress.


This would impair inclinometer accuracy and MEMS reliability.

- Do not use a hammer to align the inclinometer.
- Avoid impact stress.

4.2.2 Axes Orientation

1 dimensional - Rotation angle


Z axis: Longitudinal (long) 0 ... 360°



2 dimensional - Orientation angle

X axis: Longitudinal (long) $\pm 85^\circ$

Y axis: Lateral (lat) $\pm 85^\circ$



5 Commissioning and Operation






5.1 Function and Status LED

A multicolored LED signals the bus, operating and error status of the sensor.

Green = BUS status

Blue = BUS internal ERR display

Red = BUS ERR display

Display	LED	Meaning	Error cause	Addition
LED off		no voltage		
Green		J1939 Address claimed Device operates error-free	no error Connection interrupted (see annex)	An interruption of the connection cannot be detected in non-cyclic operation.
LED Red flashing (500 ms)		J1939 Address claimed Configuration error, sensor provides no measured data		Signal IN88_Error of the transmitted measured data has value 0xe, the other measured data is filled up with binary 1
Red (constantly on)		BUS OFF status J1939 Address conflict J1939 Address claim lost Cyclic transmission interrupted	Short-circuit on the J1939 bus or wrong baud rate, no ACK on the J1939 Bus, address conflict on the J1939 bus	Device sends no data on the bus
Blue flickering (100 ms)		Internal error in the sensor Sensor provides no measured data (Measured data is filled up with binary 1)	Send the device to the Kübler support for servicing.	Signal IN88_Error of the transmitted measured data has value 0xd, the other measured data is filled up with binary 1

5.2 Quick Start Guide

5.2.1 Default Settings

The sensor has been set in the factory as follows:

Signal name	Standard value
Resolution	100 (for 1-axis variant) 10 (for 2-axes variant)
LongOperatingPar	0x02 (Scaling ON, Inversion OFF)
LatOperatingPar	0x02 (Scaling ON, Inversion OFF)
SensorCycleTime	100 (100 ms)
BitRate	0 (250 kbps)
CANBusTermination	1 (ON)
J1939 address	0x20 (dec. 32)
FilterConfig	0x06 (10 Hz)

NOTICE	Resetting to the delivery condition
	<p>The device has no special function for resetting to the delivery condition, since all adjustable and storable parameters are set anew when sending the configuration PG.</p> <p>A separate frame must be sent to the sensor to reset the sensor to the delivery condition. Example: Resetting to Factory Settings [► 31].</p>

5.2.2 Changing the Parameters

At start-up, the sensor sends a J1939 address claim message including, among others, its device address and the least significant bits of its serial number.

- ✓ Carry out the electrical installation (voltage supply, bus connection).
 - a) Switch the device on
 - b) Have the address claiming carried out.
- ⇒ Display lights red: Check of the CAN communication (CAN_H, CAN_L), active CAN node must be present, termination, baud rate (default: 250kbit/s or 500 kbit/s).
- ⇒ Display lights green: J1939 address claim and configuration carried out properly.

NOTICE	Sensor setting time
	<p>The measured values of the sensors require a setting time of approximately 500 ms after firmware start. Setting is necessary for all signals between 0 and 0x06, which are configured to a value with CFG_Filter_Config.</p>

The sensor starting phase is structured as follows:

- The sensor starts its firmware after applying the power supply.
- The sensor sends the address claim as soon as the CAN bus is available.

- As specified in the J1939 protocol specification, the sensor waits 250 ms for a response to the address claim (e. g. in case its address is already occupied).
- The sensor waits additional 250 ms for the setting of the internal measured values in order to avoid possible strong fluctuations of the measured values at the beginning (independent of CFG_Filter_Config).
- The sensor transmits frames with measured values in the configured cycle time.

The configuration PG allows setting the following parameters:

- Resolution
- Scaling
- Preset
- Cycle time
- Device address
- Bit rate
- Termination
- Filter

The device address of the sensor can be modified by sending the COMMANDED ADDRESS (CA) PGN to the sensor. The new address is stored in non-volatile manner in the Flash memory of the sensor. The sensor restarts with the new address and sends its address claim and, if any, measured values from the new address.

ATTENTION

Service life of the Flash memory

Every sensor configuration by sending the configuration PG to the sensor causes the sensor to write its configuration in the Flash memory. This is also the case if already set configuration values are written again.

The Flash memory used in the sensor is specified for at the maximum 10,000 writing cycles. The service life of the Flash memory is reached when exceeding 10,000 writing cycles, which may lead to sensor malfunction.

In the event of a fault, contact our support. Contact [34]

5.3 Protocol Features

5.3.1 Data Transmission

All of the data is transmitted per device with a specific identifier - CAN-ID. The CAN-ID precedes every message transmitted or received by the device and is composed as follows:

Priority	PGN	Target address	Source address
0x18	0xEB00	0x20	0x05

This results for example in the following CAN-ID: 0x18EB2005

The priority determines which messages are processed first. In the event of a conflict – when two messages are transmitted simultaneously – the message with the lowest priority value is processed first. If two devices transmit with the same priority, the message of the device closest to the control in the topology is processed first.

NOTICE	CAN-ID priority
	The default priority preset in the device for all messages is 18. If other priorities are required, this must be implemented in a separate firmware.

As standard, the sensor uses the following J1939 PGN for data transmission:

- Receive configuration or End of Message message: PGN : 0xEF00 through transport protocol CMTD
- Process data transmission: PGN : 0xFFAB
- Configuration transmission 0xEB00
- TPCM through CMTD: 0xEC00
- Assembled configuration (is not transmitted via the BUS): 0xEF00

NOTICE	PGN (PG number) determination
	Upon customer request, other PG numbers can be set during sensor production, according to a special agreement with Kübler. Form sheet for configuration: kuebler.com/konfiguration_IN88

The configuration data is transmitted through J1939 CMTD transfer - as specified in document SAE J1939/21.

To transmit the data in the configuration data PG to the sensor, you can use a tool such as e. g. Vector CANoe, CANalyzer or a J1939 software stack. A configuration is However also possible without J1939 stack or without a suitable tool.

5.3.2 Layout of the Configuration Data PG

The configuration data is - as shown in the figure - structured in blocks.

Rows (horizontal)

Bytes no. 0 to 15 of the PG

Columns (vertical)

Bits 0 to 7 of every byte

	7	6	5	4	3	2	1	0
0								
INCLIN_CFG_Resolution	7	6	5	4	3	2	1	0
1								
_msb	15	14	13	12	11	10	9	8
INCLIN_CFG_LongOperatingPar								
_msb	23	22	21	20	19	18	17	16
INCLIN_SlopeLongPreset_Activate								
_msb	31	30	29	28	27	26	25	24
4								
INCLIN_SlopeLongPresetValue	39	38	37	36	35	34	33	32
5								
_msb	47	46	45	44	43	42	41	40
INCLIN_CFG_LatOperatingPar								
_msb	55	54	53	52	51	50	49	48
INCLIN_SlopeLatPreset_Activate								
_msb	63	62	61	60	59	58	57	56
8								
INCLIN_SlopeLatPresetValue	71	70	69	68	67	66	65	64
9								
_msb	79	78	77	76	75	74	73	72
10								
INCLIN_CFG_TV_CycleTime	87	86	85	84	83	82	81	80
_msb	95	94	93	92	91	90	89	88
11								
INCLIN_CFG_nodeID								
_msb	103	102	101	100	99	98	97	96
12								
INCLIN_CFG_BiRate								
_msb	111	110	109	108	107	106	105	104
13								
INCLIN_CFG_CAV_Termination								
_msb	119	118	117	116	115	114	113	112
14								
INCLIN_CFG_FilterConfig								
_msb	127	126	125	124	123	122	121	120
15								
msb	127	126	125	124	123	122	121	120

NOTICE	<p>The following signals are not used for the 2-axes sensor:</p> <ul style="list-style-type: none"> - INCLIN_CFG_LatOperatingPar - INCLIN_CFG_LatPresetActivate - INCLIN_CFG_LatPresetValue <p>Please fill their values up with zeros.</p>
---------------	--

5.3.3 Layout of the Process Data PG


The process data is structured in blocks, as shown in the figure. The inclinometer transmits the process data on PGN 0xFFAB, which results in CAN-ID 0x18FFAB20 (Extended).

Rows (horizontal)

Bytes no. 0 to 7 of the PG

Columns (vertical)

Bits 0 to 7 of every byte



5.4 Configuration Parameters Description

5.4.1 Cycle Time - INCLIN_CFG_TxCycleTime

This signal allows setting in milliseconds the cycle time with which the process data (measured values) of the sensor is transmitted on the bus as a CAN frame.

A value 0xFFFF retains the value stored so far in the sensor unchanged. A value 0 deactivates the cyclic process data transmission.

5.4.2 Bit Rate - INCLIN_CFG_BitRate

This signal allows modifying the CAN bit rate of the inclinometer. If the set value is different from the previous value, the inclinometer saves the settings and restarts after some milliseconds with the new bit rate.

NOTICE	<p>Changing the bit rate during network operation</p> <p>If possible, the bit rate should not be modified when the network is in operation.</p> <p>The selected cycle time (INCLIN_CFG_TxCycleTime) must be longer than the bus transmission time of a measured values frame, so that the measured data PGN can be transmitted error-free on the bus.</p>
---------------	--

Value	Bit rate in kBit/s
0	250 (default)
1	500
0xFF	Maintain the currently active bit rate

5.4.3 Node ID - INCLIN_CFG_NodeID

This signal allows modifying the J1939 node address of the sensor and saving it immediately in non-volatile manner in the sensor.

The node address does not change if value 0xFF is set or if the current node address is set again.

If another value is set, the sensor accepts the new value as its node address, saves it and re-starts the firmware with the new node address. Alternatively, the node address can be modified with J1939 COMMANDED ADDRESS PGN (CA).

5.4.4 Termination - INCLIN_CFG_CAN_Termination

CAN is a 2-wire bus system in which all participants are connected in parallel (that is to say with short stub lines). The bus must be terminated at both ends with a 120 ohm terminating resistor in order to prevent reflections. This is necessary even in case of very short line lengths.

The 120 ohm terminating resistor can be activated and deactivated electronically.

Setting the value 1 activates the termination, setting value 0 deactivates it.

Value 0xFF maintains the current setting unchanged.

5.4.5 Resolution - INCLIN_CFG_Resolution

This signal sets the resolution of the inclinometer for all axes.

Parameter "INCLIN_CFG_Resolution" influences measuring axes long16 and lateral16.

Value	Axis(axis) resolution	Value range of axis IN88_SlopeLong for the 1-axis sensor	Value range of axes IN88_SlopeLong and IN88_SlopeLat for the 2-axes sensor
10 (hex 0x0A)	0.01°	not supported for the 1-axis sensor	-8500 to +8500
100 (hex 0x64)	0.1°	0 to 3599	-850 to +850
1000 (hex 0x3E8)	1.0°	0 to 359	-85 to +85
others	not supported		

5.4.6 X Axis Scaling - INCLIN_CFG_LongOperatingPar

This signal allows enabling or disabling the scaling, taking into account the preset of the measured values of the longitudinal axis and the inversion of the measured values (inversion, e.g. when the sensor is mounted upside down).

The following permissible values result from this:

- 0x0: Scaling off, Inversion off
- 0x01: Scaling off, Inversion on

- 0x02: Scaling on, Inversion off
- 0x03: Scaling on, Inversion on

Field	Value	Description
ms	0	Manufacturer-specific, must always be set to 0.
r	0	reserved
s (scaling)	0	Scaling off
	1	Scaling enabled
i (Inversion)	0	Inversion off
	1	Inversion enabled

Scaling

If scaling is enabled, the measured value is calculated first:

The sensor thus takes into account a possibly set preset value when calculating the measured value. If scaling is disabled, the measured value corresponds to the physically measured value.

Inversion

If inversion is enabled, the measured value of the axis is output inverted. The inversion is independent of the orientation of the device, it merely changes the sign of the output value.

NOTICE	Preset behavior in the event of inversion
	Also the preset value is inverted when inversion is enabled. If e. g. the value 40 is entered, it will be taken over as -40.

5.4.7 Preset Activation X Axis - INCLIN_SlopeLongPresetActivate

If "INCLIN_SlopeLongPresetActivate" is set to 1, the preset function is triggered once immediately upon receipt of the configuration PG and the value contained in "INCLIN_SlopeLongPresetValue" is used for triggering the preset function.

For all other values of "INCLIN_SlopeLongPresetActivate", "INCLIN_SlopeLongPresetValue" is ignored and the preset function is not triggered.

NOTICE	Taking the preset into account
	The preset setting is only taken into account when the scaling is enabled in INCLIN_CFG_LongOperatingPar.

5.4.8 Preset Value X Axis - INCLIN_SlopeLongPresetValue

Signal INCLIN_SlopeLongPresetValue allows setting the measured value IN88_Slope_Long to a desired angle value within the value range (PRESET).

Calculation of the measured value IN88_Slope_Long:

Slope long16 = physically measured angle + Difference slope long16 offset + Slope long16 offset

NOTICE	Triggering the preset
	The preset is only triggered when INCLIN_SlopeLongPresetActivate is set to 1.

After triggering the preset, the preset value is saved in a non-volatile manner in the sensor. The preset value also remains preserved when the power supply is switched off and on.

5.4.9 Y Axis Scaling - INCLIN_CFG_LatOperatingPar

This signal allows enabling or disabling the scaling, taking into account the preset of the measured values of the lateral axis and the inversion of the measured values (inversion, e.g. when the sensor is mounted upside down).

Field	Value	Description
ms	0	Manufacturer-specific, must always be set to 0.
r	0	reserved
s (scaling)	0 1	Scaling not enabled Scaling enabled
i (Inversion)	0 1	Inversion not enabled Inversion enabled

The following permissible values result from this:

- 0x0: Scaling off, Inversion off
- 0x01: Scaling off, Inversion on
- 0x02: Scaling on, Inversion off
- 0x03: Scaling on, Inversion on

Scaling

If scaling is enabled, the measured value is calculated first. The sensor thus takes into account a possibly set preset value when calculating the measured value.

If scaling is disabled, the measured value corresponds to the physically measured value.

Inversion

If inversion is enabled, the measured value of the axis is output inverted. The inversion is independent of the orientation of the device, it merely changes the sign of the output value.

- ✓ This signal is ignored for the 1-axis variant of the inclinometer.

a) Recommendation: set this signal to 0 for the 1-axis variant.

NOTICE	Preset behavior in the event of inversion
	Also the preset value is inverted when inversion is enabled. If e. g. the value 40 is entered, it will be taken over as -40.

5.4.10 Preset Activation Y Axis – INCLIN_SlopeLatPresetActivate

If INCLIN_SlopeLatPresetActivate is set to 1, the preset function is triggered once for the lateral axis immediately upon receipt of the configuration PG and the value contained in INCLIN_SlopeLatPresetValue is used for triggering the preset function.

For all other values of INCLIN_SlopeLatPresetActivate, INCLIN_SlopeLatPresetValue is ignored and the preset function is not triggered.

NOTICE	<p>Taking the preset into account</p> <p>The preset setting is only taken into account when the scaling is enabled in INCLIN_CFG_LatOperatingPar.</p> <p>This signal is ignored for the 1-axis variant of the inclinometer.</p> <p>Recommendation: set this signal to 0 for the 1-axis variant.</p>
---------------	--

5.4.11 Preset Value Y Axis - INCLIN_SlopeLatPresetValue

Signal INCLIN_SlopeLatPresetValue allows setting the measured value IN88_Slope_Lat to a desired angle value (PRESET).

The desired angle value is transmitted as a signed 16-bit value, taking into consideration the resolution set in Signal INCLIN_CFG_Resolution.

After triggering the preset, the preset value is saved in a non-volatile manner in the sensor. The preset value also remains preserved when the power supply is switched off and on. This signal is ignored for the 1-axis variant of the inclinometer.

Recommendation: set this signal to 0 for the 1-axis variant.

NOTICE	<p>Taking the preset into account</p> <p>The preset is only triggered when INCLIN_SlopeLatPresetActivate is set to 1.</p>
---------------	--

5.4.12 Filter setting - INCLIN_CFG_FilterConfig

This signal allows setting a low-pass filter. The starting point of the stop band frequency of the filter can be modified, or the filter can be totally disabled.

The filter lets pass signal portions with frequencies lower than the limit frequency almost without attenuation. In contrast, it attenuates signal portions with higher frequencies

The default value of this setting is 0x06, i.e. the filter is enabled with a 10 Hz limit frequency.

Value (hex)	Filter enabled/disabled	Starting point of the stop band frequency of the filter
0x80	Filter disabled	--
0	Filter enabled	0.1 Hz
0x1	Filter enabled	0.3 Hz
0x2	Filter enabled	0.5 Hz
0x3	Filter enabled	1 Hz
0x4	Filter enabled	2 Hz
0x5	Filter enabled	5 Hz
0x6 (default)	Filter enabled	10 Hz
0xFF	Maintain the setting already saved	Maintain the setting already saved

A low filter frequency (e. g. value 0 or 1) leads to a strong smoothing of the measured values. When the sensor is tilted, this also means a sluggish approach of the values transmitted on the bus to the angle value measured by the sensor. Jumps in the measured values are smoothed.

On the contrary, a high filter frequency (e. g. value 5 or 6) means that the measured values will only be little smoothed. In addition, jumps and quick changes in the measured values transmitted to the bus can become visible. Description of the filter Sensor filter [▶ 36]

When the filter is disabled (value 0x80), the measured values are passed through directly and without delay. Measurement-related jumps in the values must possibly be expected.

NOTICE	Relation between filter and transmission cycle time
	Note that the transmission cycle time must be set at a low value to allow transmitting also fast measured value changes on the bus (e. g. 10 ms).

5.5 Process Data Description

5.5.1 Angle Longitudinal - IN88_Slope_Long

1-axis variant

The inclinometer returns the value measured by the Z axis LONGITUDINAL16. The measured value depends on the settings of the configuration signals and on the sensor type. These values influence the calculation and the result.

NOTICE	Take care to the orientation of the device
	The Z axis of the 1-axis sensor must be oriented as perpendicular as possible to the gravity vector. Otherwise, undefined measured values may occur. If the gravity vector and the Z axis are parallel, the Euler angle cannot be calculated.

Byte 0	Byte 1
$2^7 \dots 2^0$	$2^{15} \dots 2^8$

Values range

As indicated under INCLIN_CFG_Resolution. Resolution - INCLIN_CFG_Resolution [► 21]

Internal update rate of the measured value

20 ms

2-axes variant

The inclinometer returns the value measured by the Y axis LONGITUDINAL16. The measured value depends on the settings of the configuration signals and on the sensor type. These values influence the calculation and the result.

Byte 0	Byte 1
$2^7 \dots 2^0$	$2^{15} \dots 2^8$

Values range

As indicated under INCLIN_CFG_Resolution. Resolution - INCLIN_CFG_Resolution [► 21]

Internal update rate of the measured value

20 ms

5.5.2 Angle Lateral - IN88_Slope_Lat**1-axes variant**

With the 1-axis inclinometer, signal IN88_Slope_Lat is fixedly filled with value 0xFFFF.

2-axes variant

The inclinometer returns the value measured by the X axis LATERAL16. The measured value depends on the settings of the configuration signals and on the sensor type. These values influence the calculation and the result.

Byte 0	Byte 1
$2^7 \dots 2^0$	$2^{15} \dots 2^8$

Values range

As indicated under INCLIN_CFG_Resolution. Resolution - INCLIN_CFG_Resolution [► 21]

Internal update rate of the measured value

20 ms

5.5.3 Temperature - IN88_Temperature

This signal indicates the current temperature inside of the sensor as a signed 16-bit hexadecimal value. This value allows checking the current temperature of the device.

The signal value is provided in tenths of a degree and must be divided by 10 to give the temperature value in °C.

Byte 0	Byte 1
$2^7 \dots 2^0$	$2^{15} \dots 2^8$

Values range

00...FFFFh

Example

0x103 corresponds to + 25.9 °C

Internal update rate of the measured value:

The temperature value is updated every 2 s.

Accuracy

Accuracy is ± 0.2 °C, measurement takes place inside of the sensor electronics.

5.5.4 Overflow - IN88_Overflow

1-axis variant

For the 1-axis inclinometer, this signal has no relevance and can be ignored.

2-axes variant

Returns the overflow status.

Value	Meaning
0	Sensor positioned within the valid measuring range > -85.00° & <+85.00°
1	Sensor positioned outside of the positive measuring range > +85.00°
2	Sensor positioned outside of the negative measuring range < -85.00°

5.5.5 Position - IN88_BackFront

Returns the position of the sensor.


Value	Meaning
0	Sensor upside down
1	Sensor in normal position/installation position

5.5.6 Orientation - IN88_Orientation

The orientation value returns the quadrant in which the sensor is generally tilted. The quadrants always refer to the position of the respective sensor type (see drawing).

1-axes variant

For the 1-axis sensor, the values of the respective quadrants return the complete 360° measuring range.




IMG-ID: 9007199377709835

Value	Meaning
0	Q1 225° ... 315°
2	Q2 315° ... 45°
4	Q3 45° ... 135°
6	Q4 135° ... 225°

2-axes variant

For the 2-axes sensor, the quadrants refer to the 4 axis directions: +X, -X, +Y, -Y.



IMG-ID: 9007199377711755

Value	Meaning
0	Tilting in the +Y direction
2	Tilting in the -Y direction
4	Tilting in the +X direction
6	Tilting in the -X direction

5.5.7 Error - IN88_Error

Returns the internal error status of the sensor.

Value	Meaning
0	no error
0xE	Invalid configuration (e. g. invalid value for the resolution or last preset value outside of measuring range).
0xD	Reading error when accessing to the internal sensor components. The sensor provides no measured data. It can be sent to the Kübler support for servicing.

If an internal error occurs, the other measured values are set to value 0xFF (binary 1). Do not use these.

For optimal operation, the error status must be continuously checked during plant operation.

NOTICE	Behavior in case of connection loss.
	<p>When resuming the connection with the sensor, it may happen that the sensor transmits a message that has not been transmitted yet because of the loss of the connection.</p> <p>This is a normal behavior with CAN networks, but it may lead to an error in the control.</p>

5.6 Examples

5.6.1 Example: Setting Configuration Data

Here a fictitious example of a transmission with the listing of the raw frames on the bus when transmitting the EncoderSetup PG. This example uses fictitious values to illustrate the transmission of the data.

Configuration data	Data length in bytes	Hex value (fictitious)	Hex value converted in decimal value	Endian-converted hex value
INCLIN_CFG_Resolution	2	0x0102	258	0x0201
INCLIN_CFG_LongOperatingPar	1	0x03	3	0x03
INCLIN_CFG_SlopeLongPreset_Activate	1	0x04	4	0x04
INCLIN_CFG_SlopeLongPresetValue	2	0x0506	1286	0x0605
INCLIN_CFG_LatOperatingPar	1	0x07	7	0x07
INCLIN_CFG_SlopeLatPreset_Activate	1	0x08	8	0x08
INCLIN_CFG_SlopeLatPresetValue	2	0x090a	2314	0x0a09
INCLIN_CFG_TxCycleTime	2	0x0b0c	2828	0x0c0b
INCLIN_CFG_NodeID	1	0x0d	13	0x0d
INCLIN_CFG_BitRate	1	0x0e	14	0x0e
INCLIN_CFG_CAN_Termination	1	0x0f	15	0x0f
INCLIN_CFG_FilterConfig	1	0x10	16	0x10

The data consisting in several bytes must first be Endian-converted, thus swapped byte by byte. This is necessary because J1939 transfers the data starting with the lowest-order byte. Then the data is concatenated and transmitted as shown in the layout.

This results in the following raw data stream, which must be transmitted to the sensor (by concatenating the values in the right column of the table):

02 01 03 04 06 05 07 08 0A 09 0C 0B 0D 0E 0F 10

This data must now be distributed over several CAN frames and transmitted per CMTD transport protocol. The transport protocol is necessary because at the maximum 8 user data bytes can be transmitted per CAN frame.

All mentioned CAN frames must be transmitted and received as extended frames (29-bit identifier). There must be a dwell of at least 50 ms between the transmission of the frames.

A CMTD connection must be set up first. The requesting control device has address 0x01 and the sensor has address 0x20. The parameters coded in the transmitted packet are:

- Control byte: 0x10
- Message size: 0x10
- Total number of packets: 3
- Maximum number of packets: 0xFF
- PG number: 0xEF00
- Source address: 0x05
- Destination address: 0x20

For this purpose, the following RTS packet must be transmitted to the sensor and the CTS answer from the sensor must be waited for:

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Transmit RTS request on CAN ID: 0x18EC2005	10	10	00	03	FF	00	EF	00
Receive CTS answer on CAN ID: 0x18EC0520	11	03	01	FF	FF	00	EF	00

In the next step, the control device transmits the configuration data in three CAN frames to the sensor.

The byte 0 of the frames always contains the sequence number in the data transmission.

The bytes 1-7 consecutively contain the raw data, in this example the following data:

02 01 03 04 06 05 07 08 0A 09 0C 0B 0D 0E 0F 10

In frame 3, the last 5 unused bytes are filled up with value 0xFF.

There must be a dwell of at least 50 ms between the transmission of the frames.

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Transmit TP, sequence number: 1 CAN-ID: 0x18EB2005	01	02	01	03	04	06	05	07

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Transmit TP, sequence number: 2 CAN-ID: 0x18EB2005	02	08	0a	09	0c	0b	0d	0e

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Transmit TP, sequence number: 3 CAN-ID: 0x18EB2005	03	0F	10	FF	FF	FF	FF	FF

At the end of the transmission, the sensor confirms the successful transmission:

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Receipt EoMA, CAN-ID: 0x18EC0520	13	10	00	03	FF	00	EF	00

The receipt of the confirmation completes the configuration of the sensor.

5.6.2 Example: Resetting to Factory Settings

In this example, the sensor is set to the default settings. Also the preset values of both axes are set to 0.

Configuration data	Data length in bytes	Hex value	Hex value converted in decimal value	Endian-converted hex value
INCLIN_CFG_Resolution	2	0x0064	100	0x6400
INCLIN_CFG_LongOperatingPar	1	0x02	2	0x02
INCLIN_CFG_SlopeLongPreset_Activate	1	0x01	1	0x01
INCLIN_CFG_SlopeLongPresetValue	2	0x0000	0	0x0000
INCLIN_CFG_LatOperatingPar	1	0x02	2	0x02
INCLIN_CFG_SlopeLatPreset_Activate	1	0x01	1	0x01
INCLIN_CFG_SlopeLatPresetValue	2	0x0000	0	0x0000
INCLIN_CFG_TxCycleTime	2	0x0032	50	0x3200
INCLIN_CFG_NodeID	1	0x20	32	0x20
INCLIN_CFG_BitRate	1	0x00	0	0x00
INCLIN_CFG_CAN_Termination	1	0x01	1	0x01
INCLIN_CFG_FilterConfig	1	0x06	6	0x06

The data consisting in several bytes must first be Endian-converted, thus swapped byte by byte. This is necessary because J1939 transfers the data starting with the lowest-order byte. Then the data is concatenated and transmitted as shown in the layout.

This results in the following raw data stream, which must be transmitted to the sensor (by concatenating the values in the right column of the table):

64 00 02 01 00 00 02 01 00 00 32 00 20 00 01 06

This data must now be distributed over several CAN frames and transmitted per CMTD transport protocol. The transport protocol is necessary because at the maximum 8 user data bytes can be transmitted per CAN frame.

All mentioned CAN frames must be transmitted and received as extended frames (29-bit identifier).

There must be a dwell of at least 50 ms between the transmission of the frames.

A CMTD connection must be set up first. The requesting control device has address 0x01 and the sensor has address 0x20. The parameters coded in the transmitted packet are:

- Control byte: 0x10
- Message size: 0x10
- Total number of packets: 3
- Maximum number of packets: 0xFF
- PG number: 0xEF00
- Source address: 0x01
- Destination address: 0x20

For this purpose, the following RTS packet must be transmitted to the sensor and the CTS answer from the sensor must be waited for:

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Transmit RTS request on CAN ID: 0x18EC2001	10	10	00	03	FF	00	EF	00
Receive CTS answer on CAN ID: 0x18EC0120	11	03	01	FF	FF	00	EF	00

In the next step, the control device transmits the configuration data in three CAN frames to the sensor.

The byte 0 of the frames always contains the sequence number in the data transmission.

The bytes 1-7 consecutively contain the raw data, in this example the following data:

64 00 02 01 00 00 02 01 00 00 32 00 20 00 01 06

In the last frame, the unused data bytes are filled up with the value 0xFF.

There must be a dwell of at least 50 ms between the transmission of the frames.

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Transmit TP, sequence number: 1 CAN-ID: 0x18EB2001	01	64	00	02	01	00	00	02
Transmit TP, sequence number: 2 CAN-ID: 0x18EB2001	02	01	00	00	32	00	20	00
Transmit TP, sequence number: 3 CAN-ID: 0x18EB2001	03	01	06	FF	FF	FF	FF	FF

At the end of the transmission, the sensor confirms the successful transmission:

	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Receipt EoMA, CAN-ID: 0x18EC0120	13	10	00	03	FF	00	EF	00

The receipt of the confirmation completes the configuration of the sensor.

6 Contact

You want to contact us:

Technical advice

Kübler's worldwide applications team is available on site all over the world for technical advice, analysis or installation support.

International support (English-speaking)

+49 7720 3903 952

support@kuebler.com

Kübler Germany +49 7720 3903 849

Kübler France +33 3 89 53 45 45

Kübler Italy +39 0 26 42 33 45

Kübler Austria +43 3322 43723 12

Kübler Poland +48 6 18 49 99 02

Kübler Turkey +90 216 999 9791

Kübler China +86 10 8471 0818

Kübler India +91 8600 147 280

Kübler USA +1 855 583 2537

Repair service / RMA form

In case of returns, please package the product sufficiently and attach the completed "Returns form".

www.kuebler.com/rma

Please send your return to the address below.

Kübler Group
Fritz Kübler GmbH

Schubertstraße 47
D-78054 Villingen-Schwenningen
Germany

Phone +49 7720 3903 0

Fax +49 7720 21564

info@kuebler.com

www.kuebler.com

7 Annex

7.1 Angle calculation


7.1.1 1-axis inclinometer

Rotation angle

In this setting, the output angle value is to be interpreted as a rotation angle. The "Rotation angle Z" corresponds to the angle [°] by which the sensor has been rotated around the Z axis.

NOTICE	Comply with the maximum Z axis deflection.
	The sensor also outputs the angle around the Z axis if the Z axis, which normally is at 90° with respect to the gravity vector, is deflected with respect to the gravity vector. However, this is only possible up to the horizontal sensor position. In horizontal position, the Z rotation angle cannot be determined.

Z axis: Longitudinal (long)



IMG-ID: 9007199377709835

7.1.2 2-axes inclinometer

Orientation angles


Indicating the two orientation angles describes the inclination of the coordinate system of the sensor with respect to the gravitational direction.

The first value output corresponds to a rotation around the Y axis of the sensor and is called "Orientation angle Y". This value corresponds to the angle [°] formed by the gravity vector with the YZ plane of the sensor.

The second value output corresponds to a rotation around the X axis of the sensor and is called "Orientation angle X". This value corresponds to the angle [°] formed by the gravity vector with the XZ plane of the sensor.

X axis: Longitudinal (long)

Y axis: Lateral (lat)



IMG-ID: 9007199377711755

7.2 Sensor filter

Filter description 1st order

In electronics, low-pass filters are filters that let pass signal portions with frequencies lower than their limit frequency almost without attenuation and attenuate signal portions with higher frequencies.

Setting possibilities: Filter on/off

Filter operating frequency b: defines the starting point of the stop band (range 0.1 ... 10.0 Hz)

Filter description 2nd order


An IIR filter is generally realized with the help of 2nd order subsystems in direct form.

The following picture shows the corresponding block diagram. A subsystem consists of 2 delay elements or memory elements that contain the intermediate values $w_0(n)$ as well as of the two coefficients a^0_1 , a^0_2 in the recursive portion and the three coefficients b^0_0 , b^0_1 and b^0_2 .

Functioning

The second index (j) is used for differentiation in case of several subsystems. A subsystem is described by equations, see below. The device uses 4 2nd order subsystems, resulting in an 8th order Butterworth filter.

x_n is here the input signal, y_n is the filter output and simultaneously the input of another subsystem.



IMG-ID: 151303947

$$w_0(n) = x(n) + a_1^0 \times w_0(n-1) + a_2^0 \times w_0(n-2)$$

$$y_0(n) = b_0^0 \times w_0(n) + b_1^0 \times w_0(n-1) + b_2^0 \times w_0(n-2)$$

7.3 Decimal / Hexadecimal conversion table

Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex
0	0	51	33	102	66	153	99	204	CC
1	1	52	34	103	67	154	9A	205	CD
2	2	53	35	104	68	155	9B	206	CE
3	3	54	36	105	69	156	9C	207	CF
4	4	55	37	106	6A	157	9D	208	D0
5	5	56	38	107	6B	158	9E	209	D1
6	6	57	39	108	6C	159	9F	210	D2
7	7	58	3A	109	6D	160	A0	211	D3
8	8	59	3B	110	6E	161	A1	212	D4
9	9	60	3C	111	6F	162	A2	213	D5
10	0A	61	3D	112	70	163	A3	214	D6
11	0B	62	3E	113	71	164	A4	215	D7
12	0C	63	3F	114	72	165	A5	216	D8
13	0D	64	40	115	73	166	A6	217	D9
14	0E	65	41	116	74	167	A7	218	DA
15	0F	66	42	117	75	168	A8	219	DB
16	10	67	43	118	76	169	A9	220	DC
17	11	68	44	119	77	170	AA	221	DD
18	12	69	45	120	78	171	AB	222	DE
19	13	70	46	121	79	172	AC	223	DF
20	14	71	47	122	7A	173	AD	224	E0
21	15	72	48	123	7B	174	AE	225	E1
22	16	73	49	124	7C	175	AF	226	E2
23	17	74	4A	125	7D	176	B0	227	E3
24	18	75	4B	126	7E	177	B1	228	E4
25	19	76	4C	127	7F	178	B2	229	E5
26	1A	77	4D	128	80	179	B3	230	E6
27	1B	78	4E	129	81	180	B4	231	E7
28	1C	79	4F	130	82	181	B5	232	E8
29	1D	80	50	131	83	182	B6	233	E9
30	1E	81	51	132	84	183	B7	234	EA

Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex
31	1F	82	52	133	85	184	B8	235	EB
32	20	83	53	134	86	185	B9	236	EC
33	21	84	54	135	87	186	BA	237	ED
34	22	85	55	136	88	187	BB	238	EE
35	23	86	56	137	89	188	BC	239	EF
36	24	87	57	138	8A	189	BD	240	F0
37	25	88	58	139	8B	190	BE	241	F1
38	26	89	59	140	8C	191	BF	242	F2
39	27	90	5A	141	8D	192	C0	243	F3
40	28	91	5B	142	8E	193	C1	244	F4
41	29	92	5C	143	8F	194	C2	245	F5
42	2A	93	5D	144	90	195	C3	246	F6
43	2B	94	5E	145	91	196	C4	247	F7
44	2C	95	5F	146	92	197	C5	248	F8
45	2D	96	60	147	93	198	C6	249	F9
46	2E	97	61	148	94	199	C7	250	FA
47	2F	98	62	149	95	200	C8	251	FB
48	30	99	63	150	96	201	C9	252	FC
49	31	100	64	151	97	202	CA	253	FD
50	32	101	65	152	98	203	CB	254	FE
								255	FF

Glossary

BAM

Broadcast Announce Message

CA

Commanded Address

CAN

Controller Area Network

CAN-ID

CAN Identifier - Assembled messages identifier per device

CFG

Configuration

CMDT

Connection Mode Data Transfer

CTS

Clear To Send

Diag

Diagnostic

EMC

Electromagnetic compatibility

EoMA

End of Message Acknowledge

GND

Ground

IIR

Infinite Impulse Response (filter)

LED

Light Emitting Diode

MEMS

Micro-Electro-Mechanical Systems

PE

Protective Earth

PELV

Protective Extra Low Voltage. Functional extra-low voltage with electrically safe isolation

PG

Parameter Group

PGN

Parameter Group Number

RTS

Request To Send

TPCM

Transport Protocol Connection Management



Kübler Group
Fritz Kübler GmbH
Schubertstr. 47
D-78054 Villingen-Schwenningen
Germany
Phone +49 7720 3903-0
Fax +49 7720 21564
info@kuebler.com
www.kuebler.com